

User manual

Configuring the BIN-F0801-1 device

Version 1.0

Content

1. [Introduction](#)

- 1.1. [Purpose and functionality](#)
- 1.2. [Device and controls](#)
- 1.3. [Installation and connections](#)
- 1.4. [Dimensions](#)

2. [Configuring](#)

- 2.1. [Parameters. General](#)
- 2.2. [Parameters. Configuring binary input channel](#)
- 2.3. [Parameters. Configuring LED output channel](#)
- 2.4. [Parameters. Configuring temperature sensor channel](#)
- 2.5. [Parameters. Configuring light sensor channel](#)
- 2.6. [Parameters. Configuring humidity sensor channel](#)
- 2.7. [Parameters. Configuring buzzer output](#)
- 2.8. [Parameters. Configuring leak sensor input](#)
- 2.9. [Parameters. Configuring thermostat](#)
- 2.10. [Parameters. Configuring Calculation module](#)

3. [Communication objects](#)

- 3.1 [General](#)
- 3.2 [Binary input channel](#)
- 3.3 [LED output channel](#)
- 3.4 [Temperature sensor channel](#)
- 3.5 [Brightness sensor channel](#)
- 3.6 [Humidity sensor channel](#)
- 3.7 [Calculation module](#)

4. [Appendix](#)

- 4.1 [Appendix 1. Terms](#)


1. Introduction

1.1 Purpose and functionality

A module of binary inputs/outputs, temperature sensors and a leak sensor in a compact housing for installation in a mounting box (sub-cabinet)


- Up to 8 binary inputs
 - Short/long press
 - Switch mode
 - Pulse counter
 - Activation of scenes
 - Working with a dimmer
 - Sending numeric constants
 - Curtain management
- Up to 8 LED outputs
- Up to 4 NTC temperature sensors
- Up to 4 loops with digital temperature sensors (up to 4 sensors on each loop, with the function of averaging, maximum, minimum values)
- Up to 4 light sensors
- Up to 4 digital humidity sensors
- Connection of a passive sound source of the "piezoelectric emitter" type
- Connector for connection of a leak sensor of the "Neptune" type
- 4 thermostats
- 20 logic modules with a choice of one of 31 functions for each
- Powered by KNX bus


1.2 Device and controls




1. Terminals for connecting the KNX bus
2. Programming button
3. Programming indication
4. Cable connector E, F channels
5. Cable connector G, H channels
6. Connector of the "Neptun" type leak sensor
7. Screw terminal block

1.3. Installation and connections



Terminal	Picture	ETS	Purpose	Accessory, note
A, B, C, D 2*		Binary input	A "dry contact" type input for connecting a switch, a button	
A, B, C, D 2*		Temperature sensor	Input for an analog temperature sensor of the NTC type	NTC-S0101-1 NTC-S0130-1 NTC-S0130-2 NTC-S0101-3
A, B, C, D 1*, 2*		LED output	Output for LED type indicator, permissible current up to 2mA	
A, B, C, D 1*, 2*		Humidity sensor	Digital humidity sensor input	OWH-S0102-1
A, B, C, D 1*, 2*		Temperature sensor	Digital temperature sensor input	OWR-S0130-1
A 2*		Buzzer	Output for a passive piezo sound emitter (2000-6000 Gz)	BUZ-S2000-1 BUZ-S4000-1
A, B, C, D 1*, 2*		Light sensor	Digital light sensor input	

1.4. Dimensions



2. Configuring

2.1. Parameters. General

General	
Water leak sensor	Startup delay <input type="text" value="2"/> sec
Binary input E Hall	Availability notifications <input checked="" type="checkbox"/>
Binary input G Spots	Period <input type="text" value="10"/> sec
LED output F Hall	A: Mode <input type="text" value="Buzzer"/>
LED output H Spots	B: Mode <input type="text" value="Temperature sensor"/>
Temperature B Floor	C: Mode <input type="text" value="Brightness sensor"/>
Brightness C Window	D: Mode <input type="text" value="Humidity sensor"/>
Humidity D Hall	E: Mode <input type="text" value="Binary input"/>
Buzzer A Confirm	F: Mode <input type="text" value="LED output"/>
+ Thermostat 1 Floor	G: Mode <input type="text" value="Binary input"/>
+ Module 1 Any Leak	H: Mode <input type="text" value="LED output"/>
	Water leak sensor <input checked="" type="checkbox"/>
	Thermostats <input type="text" value="1"/>
	Calculation modules <input type="text" value="1"/>
	Hide pictures and hints <input type="checkbox"/>

«Startup delay»

Possible values: {2...60} seconds.

The device starts to be active after the specified number of seconds after power is turned on.

«Availability notifications», «Period»

Possible values: {Off/On}, Possible values: {10...600} seconds.

The «Notification. Alive» object becomes available, which transmits "1" with the specified period.

«A: Mode»

Possible values: {«Disabled», «Binary input», «LED output», «Temperature sensor», «Brightness sensor», «Humidity sensor», «Buzzer»}

- «Disabled»: terminal is not configured for use
- «Binary input»: terminal is configured as an input for connecting a button or switch. See Chapter [2.3. Configuring binary input channel](#).
- «LED output» - terminal is configured as an output for controlling an LED or other low-power consumer.
- «Temperature sensor»: terminal is configured as an input for connecting an analog or digital temperature sensor (set of sensors).
- «Brightness sensor»: terminal is configured as an input for connecting a digital light sensor (set of sensors).

- «Humidity sensor»: terminal A is configured as an input for connecting a digital humidity sensor (set of sensors).
- «Buzzer»: terminal is configured as an output for controlling a piezoelectric passive buzzer.

«B: Mode»

Possible values: {«Disabled», «Binary input», «LED output», «Temperature sensor», «Brightness sensor», «Humidity sensor»}

The principles of setting like the "[A: Mode](#)" parameter

«C: Mode»

Possible values: {«Disabled», «Binary input», «LED output», «Temperature sensor», «Brightness sensor», «Humidity sensor»}

The principles of setting like the "[A: Mode](#)" parameter

«D: Mode»

Possible values: {«Disabled», «Binary input», «LED output», «Temperature sensor», «Brightness sensor», «Humidity sensor»}

The principles of setting like the "[A: Mode](#)" parameter

«E: Mode»

Possible values: {«Disabled», «Binary input», «LED output»}

- «Disabled»: terminal is not configured for use
- «Binary input»: terminal is configured as an input for connecting a button or switch. See Chapter [2.3. Configuring binary input channel](#).
- «LED output» - terminal is configured as an output for controlling an LED or other low-power consumer. See Chapter [2.4. Configuring LED output channel](#)

«F: Mode»

Possible values: {«Disabled», «Binary input», «LED output»}

The principles of setting like the "[E: Mode](#)" parameter

«G: Mode»

Possible values: {«Disabled», «Binary input», «LED output»}

The principles of setting like the "[E: Mode](#)" parameter

«H: Mode»

Possible values: {«Disabled», «Binary input», «LED output»}

The principles of setting like the "[E: Mode](#)" parameter

«Leak sensor»

Possible values: {Off/On}

The connector for connecting a wired leak sensor of the "Neptun" type is activated. The Leak Sensor channel becomes available for configuration. The setup is described in Chapter [2.8. Configuring the leak sensor input channel](#).

«Thermostats»

Possible values: {0...4}

The number of thermostats available for configuration. Setting up each of them is described in Chapter [2.9. Configuring thermostat](#)

«*Calculation modules*»

Possible values: {0...20}

The number of calculation modules available for configuration. The configuration of each of them is described in Chapter [2.10. Configuring calculation module](#)

2.3. Parameters. Configuring binary input channel

The configuration of any of the binary inputs is performed uniformly.

--- BIN-F0801-1 > Binary input A Spot

General	Name	<input type="text" value="Spot"/>
Binary input A Spot	Device type	<input style="border: none; background-color: #f0f0f0; width: 100%;" type="text" value="Push button"/>

«*Name*»

Possible values: String up to 20 characters long

The name of the channel is displayed in the header of the settings tab and the communication objects corresponding to the channel

«*Device type*»

Possible values: {«Push button», «Switch», «Pulse counter»}

Defines the type of device connected to the binary input channel and the scheme of working with it

Device type: «Button»

A dry contact or a device simulating it (an open collector) with automatic return to the initial position is connected to the binary input channel, the result is an action determined by the channel function.

+Communication objects

- Binary input, short press (data type depends on the settings)
- Binary input, long press (data type depends on the settings)

Name	<input type="text" value="Spot"/>
Device type	<input type="text" value="Push button"/>
Contact type	<input checked="" type="radio"/> Normally open <input type="radio"/> Normally closed
Debounce time	<input type="text" value="50"/> ms
Function	<input type="text" value="Bit 0"/>
Send periodically	<input checked="" type="checkbox"/>
Period	<input type="text" value="30"/> <input checked="" type="radio"/> Seconds <input type="radio"/> Minutes
Send delay	<input type="text" value="0"/> ms
Lock object	<input checked="" type="checkbox"/>
Invert control value	<input type="checkbox"/>
Startup state	<input type="text" value="Unlocked"/>
Action on event	<input checked="" type="radio"/> Release <input type="radio"/> Push

Long press	<input checked="" type="checkbox"/>
Long press time	<input type="text" value="500"/> ms
Function	<input type="text" value="Bit 1"/>
Send periodically	<input checked="" type="checkbox"/>
Period	<input type="text" value="30"/> <input checked="" type="radio"/> Seconds <input type="radio"/> Minutes
Send delay	<input type="text" value="0"/> ms
Lock object	<input checked="" type="checkbox"/>
Invert control value	<input checked="" type="checkbox"/>
Startup state	<input type="text" value="Unlocked"/>

«Contact type»

Possible values: {«Normally open», «Normally closed»}

The parameter determines the initial position of the button. The device will perform an action defined by the settings when exiting this position or when entering.

«Debounce time»

Possible values: {0...50...250} milliseconds

The time of stabilization of the input state when the contact is closed or opened

«Function»

Possible values: {«No action», «Bit 0», «Bit 1», «Toggle bit 0/1», «Switching with return to initial state», «Shutter control», «Dimmer control», «Scene», «Scene storing», «Percentage, %», «Temperature, °C», «Relative humidity, %», «1-byte integer constant», «2-bytes integer constant»}

- **«No action»:** device does not perform any actions for a short press of the button, but an action for a long press of the button can be determined.
- **«Bit 0»:** value "0" will be sent to the KNX bus
- **«Bit 1»:** value "1" will be sent to the KNX bus
- **«Toggle bit 0/1»:** value opposite to the current state of the object will be sent to the KNX bus.

«Startup value»

Possible values: {«0», «1», «Stored value»}

Channel status at device startup

- **«Switching with return to initial state»:** value opposite to the initial state will be sent to the KNX bus, then when the button is released, the original value will be sent again

«Startup value»

Possible values: {«0», «1»}

When the button is pressed, the value opposite to the initial value is sent to the bus, when released, the specified initial value is sent.

- **«Shutter control»:** set of settings and communication objects for managing shutter/blinds

«Shutter command»

Possible values: {«Up», «Down», «Up/Down», «Stop/Step Up», «Stop/Step Down», «Stop/Step Up/Down»}

+Communication object: «Shutter move direction » DPT_UpDown [1.008] (when {«Up», «Down», «Up/Down», «Stop/Step Up»})

+Communication object: «Shutter stop/step» DPT_Step [1.007] (when «Stop/Step Up», «Stop/Step Down», « Stop/Step Up/Down»)

«Stop on next click»

With the values "Up", "Down" and "Up/Down" parameter "Shutter command"

Possible values: {Off/On}

+Communication object: «Shutter stop» DPT_Trigger [1.017]

Reactivation causes the stop command ("1") to be sent to an additional communication object.

«Position control of shutter/blinds»

With the values "Up/Down" and "Stop/Step Up/Down" parameter "Shutter command"

Possible values: {Off/On}

+Communication object: «Shutter position» DPT_Scale [5.001]

An object that takes the current position of the curtains and allows you to determine the necessary direction of movement when activating an action (Up or down)

- **«Dimmer control»:** set of settings and communication objects for dimmer control

«Dimmer command»

Possible values: {«Off», «On», «On/Off», «Brighter», «Darker», « Brighter/Darker»}

+Communication object: «Dimming» DPT_Control_Dimming [3.007] (for parameter values «Brighter», «Darker», « Brighter/Darker»)

+Communication object: «Dimmer switch» DPT_Switch [1.001] (for parameter values {«Off», «On», «Off/On»})

«Step size»

With the values «Brighter», «Darker», «Brighter/Darker» parameter «Dimmer command»

Possible values: {100%, 50%, 25%, 12.5%, 6.25%, 3.125%, 1.5625%}

«Send periodically»

For values other than 100% of the parameter «Step size»

Possible values: {Off/On}

Enabling the mode of periodic sending of the step value with the specified period.

«Step period»

Possible values: {100 ms, 200 ms, 300 ms, 500 ms, 1 sec, 2 sec, 3 sec, 5 sec}

«Stop on next click»

With the values «Brighter», «Darker», «Brighter/Darker» parameter «Dimmer command»

Possible values: {Off/On}

Enabling the option to send a stop brightness change command when the binary input is reactivated

«Dimmer status monitoring»

With the values «On/Off» u «Brighter/Darker» параметра «[Dimmer command](#)»

Possible values: {Off/On}

+Communication object: «Dimming status» DPT_Scale [5.001]

An object that accepts the current state of the dimmer and allows you to define the necessary command when activating an action.

- «**Scene**»: scene number defined by the "Scene" parameter will be sent to the KNX bus

«Scene»

Possible values: {1...64}

- «**Scene storing**»: scene number defined by the "Scene" parameter with the "Record" flag will be sent to the KNX bus

«Scene»

Possible values: {1...64}

- «**Percentage, %**»: percentage constant defined by the "Value" parameter will be sent to the KNX bus

«Value»

Possible values: {0...100} %

- «**Temperature, °C**»: temperature constant defined by the "Value" parameter will be sent to the KNX bus

«Value»

Possible values: {-100,0...0...100,0} °C

- «Relative humidity, %»: humidity constant defined by the "Value" parameter will be sent to the KNX bus

«Value»

Possible values: {0...100} %

- «**1-byte integer constant**»: 1-byte integer constant defined by the "Value" parameter will be sent to the KNX bus

«Value»

Possible values: {0...255}

- **«2-bytes integer constant»:** 2-bytes integer constant defined by the "Value" parameter will be sent to the KNX bus

«Value»

Possible values: {0...65535}

«Send on startup»

With the values «Toggle bit 0/1», «Switching with return to initial state» of parameter «Function»

Possible values: {Off/On}

Sending the value of the "Startup value" parameter to the bus when starting the Device.

«Send periodically»

Possible values: {Off/On}

«Period»

Possible values: {10...240} seconds or {1...240} minutes

«Delay in sending»

Possible values: {0...6000} milliseconds

The time for which the sending of the generated command will be postponed. When forming the next command before the expiration of this time, the previous one will be reset, and the countdown will start again

«Lock object»

Possible values: {Off/On}

+Communication object «Lock» DPT_Switch [1.001]

«Invert control value»

Possible values: {Off/On}

«Startup state»

Possible values: {«Unlocked», «Locked», «Last state»}

«Action on event»

Possible values: {«Release», «Push»}

«Long press»

Possible values: {Off/On}

Enabling the functionality of the binary input channel response to long button clicks

«Long press time»

Possible values: {100...500...6000} milliseconds

Time that the button must be pressed to recognize the "Long press" event

«Function»

Possible values: {«Bit 0», «Bit 1», «Toggle bit 0/1», «Switching with return to initial state», «Shutter control», «Dimmer control», «Scene», «Scene storing», «Percentage, %», «Temperature, °C», «Relative humidity, %», «1-byte integer constant», «2-bytes integer constant»}

Actions of the long press are like the functions of the short press, except for the features associated with stopping the curtains and dimmer.

«*Delay in sending*»

Possible values: {0...6000} milliseconds

Time for which the sending of the generated command will be postponed. When forming the next command before the expiration of this time, the previous one will be reset, and the countdown will start again

«*Lock object*»

Possible values: {Off/On}

+Communication object «Lock» DPT_Switch [1.001]

«*Invert control value*»

Possible values: {Off/On}

«*Startup state*»

Possible values: {«Unlocked», «Locked», «Last state»}

Device type: «Switch»

A dry contact or a device simulating it with fixation in each of the two positions is connected to the binary input channel, the results are actions determined for closing and opening. Contact closing corresponds to the falling edge of the input signal, the opening corresponds to the rising edge.

+Communication objects

- Binary input, contact opening (data type depends on the settings)
- Binary input, contact closing (data type depends on the settings)

Debounce time	<input type="text" value="50"/>	ms
Opening contact action	<input type="text" value="Bit 0"/>	
Send on startup	<input type="checkbox"/>	
Send delay	<input type="text" value="0"/>	ms
Lock object	<input checked="" type="checkbox"/>	
Invert control value	<input type="checkbox"/>	
Startup state	<input type="text" value="Unlocked"/>	
<hr/>		
Closing contact action	<input type="text" value="Bit 1"/>	
Send on startup	<input type="checkbox"/>	
Send delay	<input type="text" value="0"/>	ms
Lock object	<input checked="" type="checkbox"/>	
Invert control value	<input checked="" type="checkbox"/>	
Startup state	<input type="text" value="Unlocked"/>	

«*Debounce time*»

Possible values: {0...50...250} milliseconds

The time of stabilization of the input state when the contact is closed or opened

«Opening contact action»

Possible values: {«No action», «Bit 0», «Bit 1», «Toggle bit 0/1», «Scene», «Percentage, %», «Temperature, °C», «Relative humidity, %», «1-byte integer constant», «2-bytes integer constant»}

«Send on startup»

Possible values: {Off/On}

Sending the configured value to the bus when the Device is started.

«Delay in sending»

Possible values: {0...6000} milliseconds

Time for which the sending of the generated command will be postponed. When forming the next command before the expiration of this time, the previous one will be reset, and the countdown will start again

«Lock object»

Possible values: {Off/On}

+Communication object «Lock» DPT_Switch [1.001]

«Invert control value»

Possible values: {Off/On}

«Startup state»

Possible values: {«Unlocked», «Locked», «Last state»}

«Closing contact action»

Possible values: {«No action», «Bit 0», «Bit 1», «Toggle bit 0/1», «Scene», «Percentage, %», «Temperature, °C», «Relative humidity, %», «1-byte integer constant», «2-bytes integer constant»}

Configuring is like the section [«Opening contact action»](#)

Device type: «Pulse counter»

A dry contact or a device simulating it is connected to the binary input channel, the result is the number of transitions from the "closed" to "open" state or from the "open" to "closed" state. A special reset object can be used to reset to the value 0.

+ Communication objects:

- "Pulse counter " (Size depends on settings)
- "Pulse counter reset" (1-bit DPT_Trigger)

Debounce time	<input type="text" value="50"/>	ms
Pulse detection	<input checked="" type="radio"/> Rising edge <input type="radio"/> Falling edge	
Object size	<input type="text" value="1 Byte"/>	
Send delay	<input type="text" value="0"/>	ms
Lock object	<input checked="" type="checkbox"/>	
Invert control value	<input type="checkbox"/>	
Startup state	<input type="text" value="Unlocked"/>	

«Debounce time»

Possible values: {0...50...250} milliseconds

«Pulse detection»

Possible values: {«Rising edge», «Falling edge»}

The event by which the Device increases the counter, in the case of using a button or switch, the "Rising edge" setting corresponds to the opening of contacts and the "Falling edge" to the closure.

«*Object size*»

Possible values: {«1 Byte», «2 Bytes», «4 Bytes»}

Defines the type of object containing the number of counted pulses.

- 1 Byte – the communication object "Pulse counter 1 byte" is added (DPT_Value_1_Ucount [5.010])
- 2 Bytes – the communication object "Pulse counter 2 bytes" is added (DPT_Value_2_Ucount [7.001])
- 4 Bytes – the communication object "Pulse counter 4 bytes" is added (DPT_Value_4_Ucount [12.001])

«*Send delay*»

Possible values: {0...6000} milliseconds

The delay in sending each next value to the KNX bus, when each next pulse arrives, the delay starts again.

«*Lock object*»

Possible values: {Off/On}

«*Invert control value*»

Possible values: {Off/On}

«*Startup state*»

Possible values: {«Unlocked», «Locked», «Last state»}

2.4. Parameters. Configuring LED output channel

An LED or other low-power consumer with a consumption current of up to 2mA can be connected to any of the eight outputs of A....H.

Name	<input type="text" value="Check"/>
Mode	<input type="text" value="Controlled from the bus"/>
Status on startup	<input checked="" type="radio"/> Off <input type="radio"/> On
Status object	<input checked="" type="checkbox"/>
Invert	<input checked="" type="checkbox"/>
Blinking	<input checked="" type="checkbox"/>
Duration "On"	<input type="text" value="1000"/> ms
Duration "Off"	<input type="text" value="1000"/> ms
Off timer	<input checked="" type="checkbox"/>
Delay	<input type="text" value="1"/> sec
Final state	<input checked="" type="radio"/> Off <input type="radio"/> On

Lock object	<input checked="" type="checkbox"/>
Invert control value	<input checked="" type="checkbox"/>
Startup state	<input type="text" value="Unlocked"/>
Behaviour on lock	<input type="text" value="Do not change"/>
Behaviour on unlock	<input type="text" value="Do not change"/>

«Name»

Possible values: String up to 20 characters long

The name of the channel is displayed in the header of the settings tab and the communication objects corresponding to the channel

«Mode»

Possible values: {«Permanent on», «Blinking», «Controlling from the bus»}

- «Permanent on»: without control objects, the signal is constantly sent to the output of the device.
- «Blinking»: without control objects, with the ability to activate the status object. The signal is sent to the output of the device with a period according to the settings described below.

«Duration "On" »

Possible values: {100...1000...10000} milliseconds

Duration of the "On" phase

«Duration "Off" »

Possible values: {100...1000...10000} milliseconds

Duration of the "Off" phase

*«Status object»*Possible values: {Off/On}

+Communication object (DPT_State)

- «Controlling from the bus»: activation and deactivation is performed using an additional communication facility. "Switching" (DPT_Switch)

*«State on startup»*Possible values: {Off/On}*«Status object»*Possible values: {Off/On}*«Invert»*Possible values: {Off/On}*«Blinking»*Possible values: {Off/On}

In the activated state, the LED flashes with the set phase durations

*«Duration "On" »*Possible values: {100...1000...10000} milliseconds

The time in milliseconds during which the LED lights up.

*«Duration "Off" »*Possible values: {100...1000...10000} milliseconds

The time in milliseconds during which the LED does light down.

*«Off timer»*Possible values: {Off/On}

Enabling the mode in which the output is automatically deactivated after a set period

«Delay»

Possible values: {1...255} seconds

«Final state»

Available only if the "Flashing" and "Off Timer" modes are enabled.

Possible values: {Off}, «On»}

The state to which the output will be set after the time of the Off timer has expired, regardless of the flashing phase in effect at that time.

*«Lock object»*Possible values: {Off/On}*«Invert control value»*Possible values: {Off/On}*«Startup state»*Possible values: {«Unlocked », «Locked», «Last state»}*«Behavior on lock»*

Possible values: {«Off», «On», «Do not change»}

«Behavior on unlock»

Possible values: {«Off», «On», «Do not change», «Value before locking»}

2.5. Parameters. Configuring temperature sensor channel

The device allows you to connect two types of temperature sensors to each of the four inputs A...D: an analog NTC sensor manufactured by Atrél (in any of the three versions) and from one to four digital sensors connected via a two-wire circuit and combined into a loop. If there is more than one digital sensor in the loop, the Device outputs an aggregated value from all sensors operating on the loop as a temperature value according to the function selected in the settings. This allows both to obtain a more accurate temperature value for the room, and to increase the reliability of the system by a multiple of the number of sensors. In case of failure of any sensor (or several), the channel continues to work using data from the rest.

Name	<input type="text" value="Floor"/>
Type of temperature sensor	<input type="radio"/> NTC Temperature sensor <input checked="" type="radio"/> Digital temperature sensors, up to 4 pcs.
<i>i</i> From one to four ATREL OWR-50xxx-x sensors must be connected	
Data from multiple sensors	<input type="text" value="Average"/>
Check sensors online number	<input checked="" type="checkbox"/>
Minimum quantity	<input type="text" value="1"/>
Correction value	<input type="text" value="0.1"/> °C
Send when temperature changed	<input type="text" value="0.2"/> °C
Periodic sending	<input checked="" type="checkbox"/>
Period	<input type="text" value="30"/> <input checked="" type="radio"/> Seconds <input type="radio"/> Minutes
Temperature protection	<input type="text" value="Heat + Frost protection"/>
Heat alarm threshold	<input type="text" value="35"/> °C
Frost alarm threshold	<input type="text" value="7"/> °C
Hysteresis	<input type="text" value="1"/> °C

«Name»

Possible values: String up to 20 characters long

The name of the channel is displayed in the header of the settings tab and the communication objects corresponding to the channel

«Type of temperature sensor»

Possible values: {«NTC temperature sensor», «Digital temperature sensors, up to 4 pcs»}

- NTC temperature sensor - 1 NTC temperature sensor must be connected to the input
- Digital temperature sensors, up to 4 pcs – from 1 to 4 digital temperature sensors OWR-Sxxxx-x must be connected to the input

«Data from multiply sensors »

Only for the «Type of temperature sensor» value «Digital temperature sensors, up to 4 pcs»

Possible values: {«Average», «Minimum», «Maximum», «Trim extreme values»}

The setting affects the measurement result only if more than 1 digital sensor is connected to the loop. The result is a function of all sensor values on the loop.

- «Average» – the result is the arithmetic mean of all sensors on the loop
- «Minimum» – the result is the minimum value of all sensors on the loop
- «Maximum» - the result is the maximum value of all sensors on the loop
- «Trim extreme values» - the result is the average value of all sensors on the loop, except for one sensor with a minimum value and one sensor with a maximum value. If the number of sensors on the loop is less than three, it is just an arithmetic mean.

«Check sensors online number»

Only for the «Type of temperature sensor» value «Digital temperature sensors, up to 4 pcs»

Possible values: {Off/On}

Parameter for enabling the function of monitoring the number of sensors operating on the loop

«Minimum quantity »

Possible values: {1...4}

If the number of sensors on the loop is less than the specified number, then the value "1" will be set in the communication object "Sensor error", otherwise "0".

«Correction value»

Possible values: {-10...0...10} °C

«Send when temperature changed»

Possible values: {0...0.2...10} °C

«Periodic sending»

Possible values: {Off/On}

«Period»

Possible values: {10...60...240} seconds or {1...5...240} minutes

The period for sending values. The countdown starts from the moment the first value is received or the next value is sent, initiated by exceeding the minimum absolute difference from the previous one.

«Temperature protection»

Possible values: {«None», «Heat protection», «Frost protection», «Heat + frost protection»}

«Heat alarm threshold»

Possible values: {0...35...50} °C

«Frost alarm threshold »

Possible values: {0...7...50} °C

«Hysteresis»

Possible values: {0...1...50} °C

2.6. Parameters. Configuring light sensor channel

Device allows you to connect to each of the four inputs A...D from one to four specialized digital light sensors Atrel OWL-S0110-1 combined in a loop. If there is more than one digital sensor in the loop, the Device outputs an aggregated value from all sensors operating on the loop as the illumination value according to the function selected in the settings. This allows both to obtain a more accurate illumination value for the room, and to increase the reliability of the system by a multiple of the number of sensors. In case of failure of any sensor (or several), the channel continues to work using data from the rest.

--- BIN-F0801-1 > Brightness A

General	Name
Brightness A	<div style="border: 1px solid #ccc; padding: 5px; margin-bottom: 10px;"> i From one to four ATREL OWL-S0xxx-x sensors must be connected </div> <div style="display: flex; justify-content: space-between;"> <div style="width: 60%;"> Data from multiple sensors <div style="border: 1px solid #ccc; padding: 2px; margin-top: 5px;">Average</div> </div> <div style="width: 35%;"> <input checked="" type="checkbox"/> </div> </div> <div style="display: flex; justify-content: space-between; margin-top: 5px;"> <div style="width: 60%;">Check sensors online number</div> <div style="width: 35%; text-align: right;">✓</div> </div> <div style="display: flex; justify-content: space-between; margin-top: 5px;"> <div style="width: 60%;">Minimum quantity</div> <div style="width: 35%; text-align: right;">1</div> </div> <div style="display: flex; justify-content: space-between; margin-top: 5px;"> <div style="width: 60%;">Correction factor</div> <div style="width: 35%; text-align: right;">1</div> </div> <div style="display: flex; justify-content: space-between; margin-top: 5px;"> <div style="width: 60%;">Correction value</div> <div style="width: 35%; text-align: right;">0 lux</div> </div> <div style="display: flex; justify-content: space-between; margin-top: 5px;"> <div style="width: 60%;">Send when brightness changed</div> <div style="width: 35%; text-align: right;">10 lux</div> </div> <div style="display: flex; justify-content: space-between; margin-top: 5px;"> <div style="width: 60%;">Periodic sending</div> <div style="width: 35%; text-align: right;">✓</div> </div> <div style="display: flex; justify-content: space-between; margin-top: 5px;"> <div style="width: 60%;">Period</div> <div style="width: 35%; text-align: right;"> 15 <input type="radio"/> Seconds <input checked="" type="radio"/> Minutes </div> </div> <hr/> <div style="display: flex; justify-content: space-between; margin-top: 5px;"> <div style="width: 60%;">Brightness protection</div> <div style="width: 35%; text-align: right;">Upper & lower threshold protection</div> </div> <div style="display: flex; justify-content: space-between; margin-top: 5px;"> <div style="width: 60%;">Upper threshold</div> <div style="width: 35%; text-align: right;">100000 lux</div> </div> <div style="display: flex; justify-content: space-between; margin-top: 5px;"> <div style="width: 60%;">Lower threshold</div> <div style="width: 35%; text-align: right;">10 lux</div> </div> <div style="display: flex; justify-content: space-between; margin-top: 5px;"> <div style="width: 60%;">Hysteresis</div> <div style="width: 35%; text-align: right;">1 lux</div> </div>

«Name»

Possible values: String up to 20 characters long

The name of the channel is displayed in the header of the settings tab and the communication objects corresponding to the channel

«Data from multiply sensors »

Only for the «Type of temperature sensor» value « Digital temperature sensors, up to 4 pcs»

Possible values: {«Average», «Minimum», «Maximum», «Trim extreme values»}

The setting affects the measurement result only if more than 1 digital sensor is connected to the loop. The result is a function of all sensor values on the loop.

- «Average» – the result is the arithmetic mean of all sensors on the loop
- «Minimum» – the result is the minimum value of all sensors on the loop
- «Maximum» - the result is the maximum value of all sensors on the loop
- «Trim extreme values» - the result is the average value of all sensors on the loop, except for one sensor with a minimum value and one sensor with a minimum value. If the number of sensors on the loop is less than three, it is just an arithmetic mean.

«Check sensors online number»

Only for the «Type of temperature sensor» value «Digital temperature sensors, up to 4 pcs»

Possible values: {Off/On}

Parameter for enabling the function of monitoring the number of sensors operating on the loop

«Minimum quantity »

Possible values: {1...4}

If the number of sensors on the loop is less than the specified number, then the value "1" will be set in the communication object "Sensor error", otherwise "0".

«Correction factor»

Possible values: {0,1...1...10}

The coefficient by which the value obtained from the sensors will be multiplied to compensate for a possible error caused by external factors

«Correction value»

Possible values: {-5000...0...5000} lux

The value that will be added to the value received from the sensors to compensate for a possible error caused by external factors. The operation is applied after multiplication by the "Correction factor"

«Send when brightness changed»

Possible values: {0...10...1000} lux

The minimum absolute difference relative to the value previously sent to the KNX bus at which the current sensor value will be sent to the KNX bus

«Periodic sending»

Possible values: {Off/On}

Enabling the periodic mode of sending sensor values regardless of the "Send when brightness changes" setting

«Period»

Possible values: {10...60...240} seconds or {1...5...240} minutes

The period for sending values. The countdown starts from the moment the first value is received or the next value is sent, initiated by exceeding the minimum absolute difference from the previous one.

«Protection by brightness level»

Possible values: {«None», «Upper threshold protection», «Lower threshold protection », «Upper & Lower threshold protection»}

«Upper threshold»

Possible values: {0...100000...200000} lux

«Lower threshold»

Possible values: {0...10...200000} lux

«Hysteresis»

Possible values: {0...1...10000}

2.4. Parameters. Configuring humidity sensor channel

The device allows you to connect to each of the four inputs A...D from one to four specialized digital humidity sensors Atrel OWH-S0110-1 combined in a loop. If there is more than one digital sensor in the loop, the Device outputs an aggregated value from all sensors operating on the loop as a humidity value according to the function selected in the settings. This allows both to obtain a more accurate humidity value for the room, and to increase the reliability of the system by a multiple of the number of sensors. In case of failure of any sensor (or several), the channel continues to work using data from the rest.

General	Name	<input type="text"/>
Humidity A	ⓘ From one to four ATREL OWH-S0xxx-x sensors must be connected	
	Data from multiple sensors	Average <input type="text"/>
	Check sensors online number	<input checked="" type="checkbox"/>
	Minimum quantity	1 <input type="text"/>
	Correction value	0 <input type="text"/>
	Send when humidity changed	5 <input type="text"/>
	Send periodically	<input checked="" type="checkbox"/>
	Period	15 <input type="text"/> <input type="radio"/> Seconds <input checked="" type="radio"/> Minutes
	Protection by humidity level	Upper & lower threshold protection <input type="text"/>
	Upper threshold	60 <input type="text"/>
	Lower threshold	20 <input type="text"/>
	Hysteresis	5 <input type="text"/>

«Name»

Possible values: String up to 20 characters long

The name of the channel is displayed in the header of the settings tab and the communication objects corresponding to the channel

«Data from multiply sensors »

Only for the «Type of temperature sensor» value «Digital temperature sensors, up to 4 pcs»

Possible values: {«Average», «Minimum», «Maximum», «Trim extreme values»}

The setting affects the measurement result only if more than 1 digital sensor is connected to the loop. The result is a function of all sensor values on the loop.

- «Average» – the result is the arithmetic mean of all sensors on the loop
- «Minimum» – the result is the minimum value of all sensors on the loop
- «Maximum» - the result is the maximum value of all sensors on the loop
- «Trim extreme values» - the result is the average value of all sensors on the loop, except for one sensor with a minimum value and one sensor with a maximum value. If the number of sensors on the loop is less than three, it is just an arithmetic mean.

«Check sensors online number»

Only for the «Type of temperature sensor» value «Digital temperature sensors, up to 4 pcs»

Possible values: {Off/On}

Parameter for enabling the function of monitoring the number of sensors operating on the loop

«Minimum quantity »

Possible values: {1...4}

If the number of sensors on the loop is less than the specified number, then the value "1" will be set in the communication object "Sensor error", otherwise "0".

«Correction value»

Possible values: {-5000...0...5000} lux

The value that will be added to the value received from the sensors to compensate for a possible error caused by external factors. The operation is applied after multiplication by the "Correction factor"

«Send when brightness changed»

Possible values: {0...10...1000} lux

The minimum absolute difference relative to the value previously sent to the KNX bus at which the current sensor value will be sent to the KNX bus

«Periodic sending»

Possible values: {Off/On}

Enabling the periodic mode of sending sensor values regardless of the "Send when brightness changes" setting

«Period»

Possible values: {10...60...240} seconds or {1...5...240} minutes

The period for sending values. The countdown starts from the moment the first value is received or the next value is sent, initiated by exceeding the minimum absolute difference from the previous one.

«Protection by humidity level»

Possible values: {«None», «Upper threshold protection», «Lower threshold protection », «Upper & Lower threshold protection»}

«Upper threshold»

Possible values: {0...20...100} %

«Lower threshold»

Possible values: {0...60...100} %

«Hysteresis»

Possible values: {0...5...50} %

2.7. Parameters. Configuring buzzer output

Connection of the buzzer is allowed only to terminal A. The buzzer model can only be of the passive piezoelectric type with a resonant frequency from 2 to 6 kHz.

+Communication object: Buzzer, switching (1-bit DPT_Switch [1.001])

General	
Buzzer A Confirmation	
Passive piezoelectric emitter only	
Name	Confirmation
Frequency	4000 Hz
Intermittent sound	<input checked="" type="checkbox"/>
Duration "On"	1000 m:
Duration "Off"	1000 m:
Auto-off timer	<input checked="" type="checkbox"/>
Delay	200 m:
Activation	Activate by any value
Lock object	<input checked="" type="checkbox"/>
Invert control value	<input type="checkbox"/>
Startup state	Unlocked
Behavior on lock	Do not change
Behavior on unlock	Do not change

«Name»

Possible values: A string limited to 20 characters.

The name of the channel to facilitate work with communication objects.

«Frequency»

Possible values: {2000...4000...6000} Hz

The frequency of the buzzer sound. The resonance frequency of the buzzer Atrel BUZ-S4000-1 is 4000Hz, Atrel BUZ-S2000-1 is 2000Hz.

«Intermittent sound»

Possible values: {Off/On}

«On» - activation of the mode in which the buzzer emits an intermittent signal instead of a constant one. The duration of the sound/silence phases is set below.

«Duration «On»

Possible values: {100...1000...10000} milliseconds

Duration of the buzzer sound phase in intermittent sound mode

«Duration «Off»

Possible values: {100...1000...10000} milliseconds

Duration of the buzzer silence phase in intermittent sound mode

*«Auto-off timer»*Possible values: {Off/On}

Enabling the buzzer auto-off mode. It is valid only for cases when the buzzer is turned on using the bus communication object.

*«Delay»*Possible values: {100...1000...60000} milliseconds

The time after which the buzzer will be automatically turned off. Short duration values are mainly used to confirm commands.

*«Invert the control»**When the "Auto-off timer" parameter is set to "Off"*Possible values: {Off/On}

Inverting the control value from the buzzer activation communication object. When the value is "On", the buzzer turns on with a value of 0, Off turns off with a value of 1.

*«Activation»**When the "Auto-off timer" parameter is set to "On"*

Possible values: {« Activate with the value "1"», « Activate with the value "0"», « Activate by any value»}

The parameter explicitly defines the value of the communication object «Buzzer. Switching" at which the buzzer starts work. It is possible to set the buzzer to activate at any (0 and 1) value of the incoming telegram. In this case, it is not possible to turn off the buzzer using a communication object and occurs only after the specified time specified in the "Delay" parameter has elapsed.

*«Lock object»*Possible values: {Off/On}

+Communication object. Lock» (1-bit DPT_Enable [1.003]) which allows you to block the activation of the buzzer

*«Invert control value»*Possible values: {Off/On}*«Startup state»*Possible values: {«Unlocked», «Locked», «Last state»}*«Behavior on lock»*Possible values: {«Off», «On», «Do not change»}*«Behavior on unlock»*Possible values: {«Off», «On», «Do not change»}

2.8. Parameters. Configuring leak sensor input

The device allows you to connect a wired sensor of the type "Neptun" SW-005, SW-007. The connection is made through a specially dedicated connector on the side surface of the Device and the supplied adapter with three 10cm-long conductors in the color scheme corresponding to the conductors of the «Neptune» sensor. It is necessary to connect by observing the colors of the conductors: "green"- "green", "red"- "red", "yellow"- "yellow"

General	State stabilization time	2	sec
Leak sensor	Send periodically	<input checked="" type="checkbox"/>	
	Period	30	<input checked="" type="radio"/> Seconds <input type="radio"/> Minutes
	Lock object	<input checked="" type="checkbox"/>	
	Invert control value	<input type="checkbox"/>	
	Startup state	Unlocked	

«State stabilization time»

Possible values: {2...60} sec

«Send periodically»

Possible values: {Off/On}

Enabling the periodic mode of sending the status of the leak sensor.

«Period»

Possible values: {10...30...240} seconds or {1...240} minutes

«Lock objects»

Possible values: {Off/On}

+ Communication objects «Lock leak sensor» DPT_Enable

«Invert control value»

Possible values: {Off/On}

When "On", the channel is blocked in the current state and stops responding to the actual state of the sensor

«Startup state»

Possible values: {«Unlocked», «Locked», «Last state»}

The status of the leak sensor channel lock mode when starting or restarting the device

2.9. Parameters. Configuring thermostat

The device allows you to set up and use up to 4 thermostats with two modes in each (Heating and Cooling) and rules for switching between them. To set up any thermostat channel, see the file "[User Manual. Configuring thermostat](#)"

2.10. Parameters. Configuring Calculation module

To configure any of the 20 calculation modules, see the file "[User Manual. Configuring the calculation module](#)"

3. Communication objects

3.1. General

ID	Name	Type	Flags
Conditions			
Description			
1	Notification. Alive	O	DPT_Trigger
When activating the "Availability notifications"			
Sending "1" with the specified period			
2	Water leak sensor. Water leak alarm	O	DPT_Alarm
With the "Water leak alarm" parameter set to "On"			
3	Water leak alarm. Lock	I	DPT_Enable
With the parameters "Water leak alarm", "Lock" set to "On"			
292	Buzzer. Switch	I	DPT_Switch
When the parameter "A: Mode" is set to "Buzzer"			
293	Buzzer. Lock	I	DPT_Enable
When the parameter "A: Mode" is set to "Buzzer" and «Lock object» to «On»			
654	Debug information	O	DPT_String_ASCII
Hidden			

3.2 Binary input channel

N is the value corresponding to the channel: for "A" - 0, for "B" - 1, and so on

ID	Name	Type	Flags
Conditions			
Description			
4+24*N	Binary input X, short press. Switching	O	DPT_Switch
Button: when selecting a function «Bit 0», «Bit 1», «Toggle 0/1», «Switching with return to initial state»			
Sending the value 0 or 1 of the button when pressing and/or releasing			
4+24*N	Binary input X, short press. Dimmer switch	O	DPT_Switch
Button: when selecting a function «Dimmer control», Commands: «Off», «On», «On/Off»			
4+24*N	Binary input X, short press. Shutter move direction	O	DPT_UpDown
Button: when selecting a function «Shutter control»			
4+24*N	Binary input X, short press. Shutter stop/step	O	DPT_Step
Button: when selecting a function «Shutter control»			
4+24*N	Binary input X, contact opening. Switching	O	DPT_Switch
Switch: when selecting a function «Bit 0», «Bit 1», «Toggle 0/1»			
5+24*N	Binary input X, short press. Lock	I	DPT_Switch
Button: when selecting a function «Lock object»			
5+24*N	Binary input X, contact opening. Lock	I	DPT_Switch
Switch: when selecting a function «Lock object»			
6+24*N	Binary input X, short press. Scene	O	DPT_SceneNumber
Button: when selecting a function «Scene»			
6+24*N	Binary input X, short press. Scene storing	O	DPT_SceneControl
Button: when selecting a function «Scene storing»			
6+24*N	Binary input X, contact opening. Scene	O	DPT_SceneNumber
Switch: when selecting a function «Scene»			
7+24*N	Binary input X, short press. Dimming	O	DPT_Control_Dimming
Button: when selecting a function «Dimmer control»			
8+24*N	Binary input X, short press. Dimming status	I	DPT_Scaling
Button: when selecting a function «Dimmer»			

9+24*N	Binary input X, short press. Shutter position <i>Button: when selecting a function «Shutter control»</i>	I	DPT_Scaling	CW
9+24*N	Binary input X, short press. Shutter stop <i>Button: when selecting a function «Shutter control»</i>	O	DPT_Trigger	CT
10+24*N	Binary input X, short press. 1-byte integer constant <i>Button: when selecting a function «1-byte integer constant»</i>	O	DPT_Value_1_Ucount	CT
10+24*N	Binary input X, contact opening. 1-byte integer constant <i>Switch: when selecting a function «1-byte integer constant»</i>	O	DPT_Value_1_Ucount	CT
11+24*N	Binary input X, short press. 1-byte percent constant <i>Button: when selecting a function «Percentage, %»</i>	O	DPT_Scaling	CT
11+24*N	Binary input X, contact opening. 1-byte percent constant <i>Switch: when selecting a function «Percentage, %»</i>	O	DPT_Scaling	CT
12+24*N	Binary input X, short press. 2-bytes integer constant <i>Button: when selecting a function «2-bytes integer constant»</i>	O	DPT_Value_2_Ucount	CT
12+24*N	Binary input X, contact opening. 2-bytes integer constant <i>Switch: when selecting a function «2-bytes integer constant»</i>	O	DPT_Value_2_Ucount	CT
13+24*N	Binary input X, short press. Temperature °C <i>Button: when selecting a function «Температура °C»</i>	O	DPT_Value_Temp	CT
13+24*N	Binary input X, contact opening. Temperature °C <i>Switch: when selecting a function «Температура °C»</i>	O	DPT_Value_Temp	CT
14+24*N	Binary input X, short press. Humidity % <i>Button: when selecting a function « Relative humidity, % »</i>	O	DPT_Value_Humidity	CT
14+24*N	Binary input X, contact opening. Humidity % <i>Switch: when selecting a function « Relative humidity, %»</i>	O	DPT_Value_Humidity	CT
15+24*N	Binary input X, long press. Switching <i>Button: when selecting a function «Bit 0», «Bit 1», «Toggle 0/1», «Switching with return to initial state»</i>	O	DPT_Switch	CRT
15+24*N	Binary input X, long press. Shutter move direction <i>Button: when selecting a function for long press «Shutter control»</i>	O	DPT_UpDown	CRT
15+24*N	Binary input X, long press. Вкл/Off диммера <i>Button: when selecting a function for long press «Dimmer»</i>	O	DPT_Switch	CRT
15+24*N	Binary input X, long press. Shutter stop/step <i>Button: when selecting a function for long press «Shutter control»</i>	O	DPT_Step	CRT
15+24*N	Binary input X, contact closing. Switching <i>Switch: when selecting a function «Bit 0», «Bit 1», «Toggle 0/1»</i>	O	DPT_Switch	CRT
16+24*N	Binary input X, long press. Lock <i>Button: when selecting a function for long press «Lock object»</i>	I	DPT_Switch	CW
16+24*N	Binary input X, contact closing. Lock <i>Switch: when selecting a function «Lock object»</i>	I	DPT_Switch	CW
17+24*N	Binary input X, long press. Scene <i>Button: when selecting a function for long press «Scene»</i>	O	DPT_SceneNumber	CRT
17+24*N	Binary input X, contact closing. Scene <i>Switch: when selecting a function «Scene»</i>	O	DPT_SceneNumber	CRT
17+24*N	Binary input X, long press. Scene storing <i>Button: when selecting a function for long press «Scene storing»</i>	O	DPT_SceneControl	CRT
18+24*N	Binary input X, long press. Dimming <i>Button: when selecting a function for long press «Dimmer»</i>	O	DPT_Control_Dimming	CT
19+24*N	Binary input X, long press. Dimming status <i>Button: when selecting a function for long press «Dimmer»</i>	I	DPT_Scaling	CW

20+24*N	Binary input X, long press. Shutter position <i>Button: when selecting a function for long press «Shutter control»</i>	I	DPT_Scaling	CW
21+24*N	Binary input X, long press. Shutter stop <i>Button: when selecting a function for long press «Shutter control»</i>	O	DPT_Trigger	CT
21+24*N	Binary input X, long press. Dimmer stop <i>Switch: when selecting a function «Dimmer»</i>	O	DPT_Switch	CT
22+24*N	Binary input X, long press. 1-byte integer constant <i>Button: when selecting a function for long press «1-byte integer constant»</i>	O	DPT_Value_1_Ucount	CT
22+24*N	Binary input X, contact closing. 1-byte integer constant <i>Switch: when selecting a function «1-byte integer constant»</i>	O	DPT_Value_1_Ucount	CT
23+24*N	Binary input X, long press. Scale <i>Button: when selecting a function for long press «Scale»</i>	O	DPT_Scaling	CT
23+24*N	Binary input X, contact closing. Scale <i>Switch: when selecting a function «Scale»</i>	O	DPT_Scaling	CT
24+24*N	Binary input X, long press. 2-bytes integer constant <i>Button: when selecting a function for long press «2-bytes integer constant»</i>	O	DPT_Value_2_Ucount	CT
24+24*N	Binary input X, contact closing. 2-bytes integer constant <i>Switch: when selecting a function «2-bytes integer constant»</i>	O	DPT_Value_2_Ucount	CT
25+24*N	Binary input X, long press. Temperature °C <i>Button: when selecting a function for long press «Temperature °C»</i>	O	DPT_Value_Humidity	CT
25+24*N	Binary input X, contact closing. Temperature °C <i>Switch: when selecting a function «Temperature °C»</i>	O	DPT_Value_Humidity	CT
25+24*N	Binary input X, long press. Humidity % <i>Button: when selecting a function for long press «Humidity, %»</i>	O	DPT_Value_Temp	CT
25+24*N	Binary input X, contact closing. Humidity % <i>Switch: when selecting a function «Relative humidity, %»</i>	O	DPT_Value_Temp	CT
26+24*N	Binary input X, Pulse counter 1 byte <i>Pulse counter: when selecting «Object size» = «1 byte»</i>	O	DPT_Value_1_Ucount	CT
27+24*N	Binary input X, Pulse counter 2 bytes <i>Pulse counter: when selecting «Object size» = «2 bytes»</i>	O	DPT_Value_2_Ucount	CT
28+24*N	Binary input X, Pulse counter 4 bytes <i>Pulse counter: when selecting «Object size» = «4 bytes»</i>	O	DPT_Value_4_Ucount	CT
29+24*N	Binary input X, Reset pulse counter <i>Pulse counter: Always</i> <i>Reset pulse counter</i>	I	DPT_Reset	CW

3.3 LED output channel

N is the value corresponding to the channel: for "A" - 0, for "B" - 1, and so on

ID	Name	Type	Flags
Conditions			
Description			
212+4*N	LED X. Switch <i>Always</i>	O	DPT_Switch CW
213+4*N	LED X. State <i>With the "Status Object" parameter set to "On"</i>	I	DPT_State RCT
214+4*N	LED X. Permanent on <i>When the "Blinking" parameter is set to "On"</i>	I	DPT_Switch CW
215+4*N	LED X. Lock <i>With the "Lock Object" parameter set to "On"</i>	I	DPT_Enable CW

3.4 Temperature sensor channel

N is the value corresponding to the channel: for "A" – 0, for "B" - 1, for "C" - 2, for "D" – 3

ID	Name	Type	Flags
Conditions			
Description			
244+4*N	Temperature sensor X. Temperature value, °C	O	DPT_Value_Temp
Always			
245+4*N	Temperature sensor X. Sensor error	O	DPT_Alarm
Always			
246+4*N	Temperature sensor X. Alert: Temperature under threshold	O	DPT_Alarm
Depending on the "Temperature protection" parameter			
247+4*N	Temperature sensor X. Alert: Temperature over threshold	O	DPT_Alarm
Depending on the "Temperature protection" parameter			

3.5 Brightness sensor channel

N is the value corresponding to the channel: for "A" – 0, for "B" - 1, for "C" - 2, for "D" – 3

ID	Name	Type	Flags
Conditions			
Description			
260+4*N	Brightness sensor X. Brightness value, lux	O	DPT_Value_Lux
Always			
261+4*N	Brightness sensor X. Sensor error	O	DPT_Alarm
Always			
262+4*N	Brightness sensor X. Alert: Brightness under threshold	O	DPT_Alarm
Depending on the "Brightness protection" parameter			
263+4*N	Brightness sensor X. Alert: Brightness over threshold	O	DPT_Alarm
Depending on the "Brightness protection" parameter			

3.6 Humidity sensor channel

N is the value corresponding to the channel: for "A" – 0, for "B" - 1, for "C" - 2, for "D" – 3

ID	Name	Type	Flags
Conditions			
Description			
276+4*N	Humidity sensor X. Relative humidity, %	O	DPT_Value_Humidity
Always			
277+4*N	Humidity sensor X. Sensor error	O	DPT_Alarm
Always			
278+4*N	Humidity sensor X. Alert: Humidity under threshold	O	DPT_Alarm
Depending on the "Humidity protection" parameter			
279+4*N	Humidity sensor X. Alert: Humidity over threshold	O	DPT_Alarm
Depending on the "Humidity protection" parameter			

3.7. Communication module

For a description of the communication objects of any of the calculation modules, see the file "[User Manual. Configuring calculation module](#)".

4. Appendixes

4.1 Appendix 1. Terms
